



Attention:

- Bolt height above flange (as shown in table below) must not exceed H for the given monitor.
- Junction box without mount is to be placed no longer than 1m from monitor. Cable glands pointing down.
- Junction box with mount is to be fixed under connecting flange with one of the monitors bolts.
- The monitor should be supported by struts close to the connecting flange to make sure that reaction forces does not compromise the piping system.
- Delivered equipment may look different than shown in this instruction.

MAX HEIGHT OF BOLTS OVER MONITOR FLANGE

Model	RCM-80 DIN	RCM-80 ANSI	RCM-100 DIN	RCM-100 ANSI	RCM-150 DIN	RCM-150 ANSI
Height [H]	20mm	35mm	20mm	40mm	25mm	55mm

PARTS LIST, STANDARD

POS	RCM AFN SOL DIN/ANSI
1	Monitor unit RCM
2	Nozzle unit AFN
3	Grooved Coupling
4	Solenoid
5	Actuator Valve
6	Manual override nut <i>CAUTION: Remove tools after use</i>
7	Manual override handle: <i>CAUTION: Refit with wing nut to original mount location after use</i>
8	Junction Box