



Instruction:

- Mount facing centre of protected area.
- Rotate (2) for rotation to allow for installation of bolts. Use 17mm socket wrench to be able to bypass manual override covers. (Remove tools after use)
- Junction box without mount is to be placed no longer than 1m from monitor.
- Junction box with mount is to be fixed under connecting flange with one of the monitors bolts.

PARTS LIST, STANDARD

POS	RCM DIN/ANSI
1	Monitor unit
2	Manual override nut <i>CAUTION: Remove tools after use</i>
3	Junction Box (Not pictured. Mounted with cable glands pointing down. Max distance 1m from monitor.)

PARTS LIST, INSTALLATION KIT (OPTIONAL)

POS	RCM DIN/ANSI
A	Bolt DIN: RCM-80,-100: M16. RCM-150: M20 ANSI: RCM-80,-100: UNC 5/8". RCM-150: UNC 3/4".
B	Gasket (Depending on monitor size)
C	Washer (Depending on monitor size)
D	Nut DIN: RCM-80,-100: M16. RCM-150: M20 ANSI: RCM-80,-100: UNC 5/8". RCM-150: UNC 3/4"

MAX HEIGHT OF BOLTS OVER MONITOR FLANGE

Model	RCM-80 DIN	RCM-80 ANSI	RCM-100 DIN	RCM-100 ANSI	RCM-150 DIN	RCM-150 ANSI
Height [H]	20mm	35mm	20mm	40mm	25mm	55mm